

XK-5 SOFTWARE RELEASE 2.5

This package contains two items:

1. This instruction sheet, and
2. A USB Flash Drive containing XK-5 Software Release 2.5

To update your XK-5 with Release 2.5 system software, do the following:

1. Insert the USB Flash Drive provided with this package into the USB Port of your XK-5. The display will show:

Confirming USB Please wait...

for about 3 seconds.

2. Touch the MENU/EXIT Touch Button. The display should look similar to this:



3. Touch the PAGE UP Touch Button **five** times. You will now see the **F** screen.
4. Touch the PAGE RIGHT Touch Button **two** times. The word “UPDATE” should now blink.
5. Touch the ENTER Touch Button to access the UPDATE Edit Menu. You will first be asked from which media you want to read the Update files. Select “USB Flash.” If “USB Flash” is not displaying, use the VALUE Rotary Knob to select “USB Flash.”
6. Press and hold the red RECORD Touch Button.
7. While holding the red RECORD Touch Button, touch the ENTER Touch Button. You can release both Touch Buttons when the Update procedure begins. The display will show a Status Bar and a percentage number showing the progress of the Update.
8. When the display shows:

Please power off
Completed!!!

the Update process will be complete.

9. Remove the USB Flash Drive from the USB Port.
10. Turn the power to the instrument “OFF,” then “ON.” The XK-5 is now updated and ready to play.