


# UPDATE

In this mode, update the system software (hereinafter, system) in this keyboard from USB flash drive, or internal memory.

The system may updated for improving the quality or stability.

To update the system, download the updatator and load into this keyboard.




## WORKING TIME AND SECURING THE POWER

Do the updating operation under the condition with enough working time and stable power secured.


The updating will take up to quarters of hours maximum. If the power is cut off during the process, this unit might not start up.

### ① COPY THE "SYS" FILES




If the updatator are archived, decompress/unzip it, and copy the "sys" files to the "system" folder of the USB Flash Drive or the Internal Memory.

To compose folders which shown above figure, insert the USB Flash Drive into the XK-5 once before copy files. And wait for "Confirming USB. Please wait." is disappeared.



**⚠ CAUTION**  
Do not rename, delete or format the internal memory. It causes the breakdown of the operating system.

### ② CHOOSE THE MEDIA THAT COPIED



When you come to the UPDATE mode, you will be first asked to which media you want to read the updatator.

Select the USB Flash or the INTERNAL MEM with the [VALUE] knob and decide with the [ENTER] button.


**NOTE:** This page does not display when the USB Flash Drive is not inserted.

### ◆ THE UPDATOR DOES NOT FOUND

No system files.


The Updatator are not found in the selected media.

### ③ UPDATE BEGINS



The status of the updating operation is displayed in percentage while it is in process.

## ④ UPDATE FINISHED



The updating process is completed when “Please power off.” is displayed.

Once turn off the power and switch on again, the unit will start up with the updated system software.